

# Error List

1 Current Measurement  
2 Hall sensors  
4 Current Measurement Offset  
8 V\_Lo<sub>gic</sub>  
10 V\_Dr<sub>ive</sub>  
20 12 V  
40 Isolated AD  
80 init required  
100 4-20 mA signal lost  
200 Calibration TBD  
400 Overheated  
800 Parameter FLASH error  
1000 Overload error  
2000 Endstop lost  
4000 Magnetcross Counter not valid  
8000 Magnetcross function failed  
10000 Stuck error  
20000 Magnets not found  
40000 Calibration Direction Error  
80000 Calibration Mech Endstop No Sensor



**Right mouse -click  
this (status) box,  
to see errors (error  
flagslist) written in  
the program**

